


Seymour
Duncan®

2 P-RAILS | 2 VOLUMES | 2 TONES 2 3-WAY MINI TOGGLE | 3 WAY TOGGLE

ON-OFF-ON (dpdt) Mini-toggle Switch Settings**



↑
UP = Rail (single coil strat sound)

MIDDLE = full humbucker sound (series)

↓
DOWN = P-90 sound

Here at Seymour Duncan, we encourage you to use and share these wiring diagrams freely. But, it really hurts our feelings if you use them in commercial use without prior written permission. Switching the wiring of your guitar is a practically free way to get new tones out of your guitar... Now go have fun!

